



| | | |
|----|------------|---|
| 1 | 1349733532 | 4 |
| 2 | 1349733273 | 2 |
| 3 | 7632733334 | 1 |
| 4 | 1349733478 | 1 |
| 5 | 1349733737 | 1 |
| 6 | 1349733583 | 1 |
| 7 | 1349733265 | 1 |
| 8 | 1349733257 | 1 |
| 9 | 1349733559 | 1 |
| 10 | 1349733605 | 1 |
| 11 | 1349733125 | 1 |
| 12 | 1349733745 | 1 |
| 13 | 7632733385 | 1 |
| 14 | 1349733036 | 1 |
| 15 | 1349733460 | 3 |
| 16 | 1349733192 | 1 |
| 17 | 1349733117 | 1 |
| 18 | 0903064854 | 1 |
| 19 | 7632733300 | 2 |

| Pozitie | Cantitate | Numar tip | Denumire | PG |
|---------|-----------|------------|--|----|
| 1 | 4 | 1349733532 | Screw PT-KB 5x20 VA TP/TPF/TPS/PS | 19 |
| 2 | 2 | 1349733273 | Handle TP/TPF/TPS/PS | 25 |
| 3 | 1 | 7632733334 | O-Ring 90x4,5 TP/TPF/TPS/PS | 19 |
| 4 | 1 | 1349733478 | Screw PT 30x3,5 TPS 14000/16000 S Combi | 14 |
| 5 | 1 | 1349733737 | Intermediate Ring TPS 14000/16000 S Comb | 28 |
| 6 | 1 | 1349733583 | Screw PT-KB 5x45 VA TP/TPF/TPS/PS | 16 |
| 7 | 1 | 1349733230 | Ball TPF 6600 SN PS 18000 SN | 11 |
| 8 | 1 | 1349733257 | Air vent sheet TP/TPF/TPS/PS | 16 |
| 9 | 1 | 1349733559 | Screw PT-KB 3x8 VA TP/TPF/TPS/PS | 11 |
| 10 | 1 | 1349733605 | Washer,6,3x15,5x1,5 A2-70 | 22 |
| 11 | 1 | 1349733125 | Impeller TPS 16000 S Combi | 27 |
| 12 | 1 | 1349733745 | Hexagonal nut | 19 |
| 13 | 1 | 7632733385 | O-Ring 150x3 TPS 14000/16000 S Combi | 17 |
| 14 | 1 | 1349733036 | PUMP CASING TPS 14000/16000 S Combi | 34 |
| 15 | 3 | 1349733460 | Schraubbolzen M5 | 19 |
| 16 | 1 | 1349733192 | Shaft Collar TPS 14000/16000 S Combi | 30 |
| 17 | 1 | 1349733117 | Pump Base TPS 16000 S Combi | 31 |
| 18 | 1 | 0903064854 | Angle Connection with Multi-Adaptor | |
| 19 | 2 | 7632733300 | O-Ring 45x3 | 14 |