



Pozitie	Cantitate	Numar tip	Denumire	PG
1	1	343445960	Holder (f. battery)	24
2	2	343445970	Guide	14
3	1	342021670	Spring clip	11
4	1	343438580	Locking slide	12
5	2	341702050	Screw	11
6	1	343430520	Locking piece	11
7	1	316096720	Handle left cpl.	29
8	1	341117690	grip strap coated	33
9	14	341722900	Self-tap. fill. h. screw	13
10	1	338129940	Indication label	12
11	1	343445980	Motor housing	26
12	1	338129000	Type label,RW 18 LTX 120	11
14	1	316053210	Brush holder compl.,18 V	23
16	1	317004970	Flange compl.	26
17	1	338068590	Leistungsschild 01163000 RW 18 LTX 120	11
18	1	343086100	electronic unit, 18V Stirrer	49
19	1	316096740	Handle right cpl.	29
20	1	343411670	Switch compl.	32
21	1	344098740	Rubber bushing	11
22	1	320050650	Ball bearing	22
23	1	316096750	Bearing Cover cpl.	39
24	1	344113760	Seal	18
25	1	341605440	Intermediate shaft	36
26	1	316096760	Gear-box cpl.	53
27	4	341722910	Self-tap. fill. h. screw	13
28	1	341212400	THREADED CONNECTION 5/8"x16 UN	31
29	1	311011880	Field coil compl.,2 pol.	34
30	1	310012290	Armature compl.,18V	36
95	2	343439680	Cover cap	11
1001	1	338506290	Wiring diagram	

