



1	1349733532	4
2	1349733273	2
3	7632733334	1
4	1349733486	1
5	1349733168	1
6	1349733516	1
7	1349733362	1
8	1349733265	1
9	1349733257	1
10	1349733559	1
11	1349733583	4
12	7632733342	1
13	1349733095	1
14	1349733540	3
15	0903064846	1
16	7632733326	2

Pozitie	Cantitate	Numar tip	Denumire	PG
1	4	1349733532	Screw PT-KB 5x20 VA TP/TPF/TPS/PS	19
2	2	1349733273	Handle TP/TPF/TPS/PS	25
3	1	7632733334	O-Ring 90x4,5 TP/TPF/TPS/PS	19
4	1	1349733486	Washer,8,4x15x0,5	14
5	1	1349733168	Impeller TP 13000 S	25
6	1	1349733516	Hexagonal nut M8 A2-70	13
7	1	1349733362	Intermediate Ring TP 13000 S PS 15000 S	29
8	1	1349733230	Ball TPF 6600 SN PS 18000 SN	11
9	1	1349733257	Air vent sheet TP/TPF/TPS/PS	16
10	1	1349733559	Screw PT-KB 3x8 VA TP/TPF/TPS/PS	11
11	4	1349733583	Screw PT-KB 5x45 VA TP/TPF/TPS/PS	16
12	1	7632733342	O-Ring 103x3 TP/PS	16
13	1	1349733095	Pump Base TP6600 S TP 8000 S TP 13000 S	31
14	3	1349733540	Screw PT-KB 5x40 VA TP/PS	16
15	1	0903064846	Angle Connection with Multi-Adaptor	
16	2	7632733326	O-Ring 38x2,5 TP/TPF/PS	17
20	1	399999990	Part not needed	