



Pozícia	Počet	Typové číslo	Označenie	PG
1	1	343454980	Gehaeuseschale unten	19
2	1	343454990	Gehaeuseschale oben	19
3	4	141113180	Sosovkovita skrutka	11
4	2	343454580	Kohledeckel	17
5	4	141117060	Sosovkovita skrutka	12
6	1	316040610	STOP VRETENA	14
7	1	316098360	Getriebegehäuse vollst.	25
8	1	341100940	Sechskantmutter m.Ansatz	12
9	1	316080780	Tellerrad und Ritzel	18
10	1	143116020	Rillenkugellager, 8X 22X 7	14
11	1	315420080	Festlagerdeckel	11
12	2	141110460	Sosovkovita skrutka	11
13	1	339007940	Scheibe	11
14	1	316080790	Rotor vollst.	34
15	1	344098740	Gummibuchse	11
16	1	311013900	Feldpaket vollst.,2 pol.	30
17	1	338129960	Hinweisschild CAS 18x18 PMMA	12
18	1	316072450	Kohlehalter vollst.	18
19	1	316060540	Kohlebürstensatz	21
20	1	316071470	Litzensatz mit Schalter	21
21	1	343090600	Elektronikeinheit,18V	36
22	1	316066720	BLOKOVANIE cpl.	14
23	2	342004180	Druckfeder	11
24	1	343447010	Einlegeteil	11
25	1	345020100	Leistungsschild	12
27	1	339060160	VYROVNAVACI KOTUC	12
29	1	345020070	O-KRUZOK	
30	1	316080770	Flansch vollst.	24
33	1	143192540	O-KRUZOK	11
34	4	141120070	Sosovkovita skrutka	11
35	1	314000540	RUKOVAT UPLNA	22
36	1	141124060	Linsenschraube	11
37	1	339209500	Schutzhaube, D 125	20
38	1	630352000	Trennschutzhauben-Clip 125 mm	
39	1	341031160	UPINACIA PRIRUBA	22
40	1	341106900	PRIRUBOVA MATICA M 14	20
41	1	344163920	DVOJDIEROVA OT.MATICA	14
42	1	339008160	SPINACIA TYC	11
43	1	342004370	Zugfeder	11
44	1	343447510	ARETACNY PUSUVAC	11
45	1	338136430	TYPOVY STITOK	12
46	1	343454590	POSUVAC VYPINACA	19
95	1	343439680	Abdeckkappe	11
880	1	344130910	TUK V TUBE 100 G	24
1001	1	338506810	SCHEMA ZAPOJENIA	