



Pozícia	Počet	Typové číslo	Označenie	PG
5	1	344104120	Abdeckung f. USB	11
7	1	144209270	NALEPKA	12
20	1	343460060	Abdeckung f. Akku vollst.	23
26	1	343456910	Fuss vollst.	25
27	1	343456920	Linse	14